


EXTRA WEIGHT FOR WINDY PLACES

In windy places, you can use an extra weight for the 60x30 and 30x30 cm bases and for the two curved bases.

BASES WITHOUT LEDS



1. Turn the base upside down and remove its feet.
2. Put the extra weight on the bottom of the base making sure the holes match up.
3. Attach the feet using the supplied longer screws

BASES WITH LEDS



1. Turn the base upside down and remove its feet.



2. Push all the cables deep into the recesses. Choose each time the recess nearest to the next base (this only applies to the 60x30 and 30x30 cm bases).



3. Put the extra weight on the bottom of the base making sure the holes match up. Push the two cables through the two outer holes.



4. Attach the feet using the supplied longer screws.